OWNERS MANUAL
INSTALLATION GUIDE
LIMITED WARRANTY

Thank you for choosing Showwheels products. Your new wheels are manufactured from quality materials to very high standards.

Please read the following information ensuring your wheels are properly installed and maintained.

Changing the wheels and tires on a vehicle can alter its performance and legality on the road. Because of this situation there are specific limits to the changes that are permitted. While these changes may be permitted it is the responsibility of the owner to ensure their vehicle remains safe even though it is modified within the specified limits. It is the vehicle owners responsibility to contact relevant road and traffic authorities prior to the modifications being undertaken to see that they are permitted.

WARNING
Serious accidents and/or injuries can occur when modifying vehicles outside permitted changes.

PRIOR TO MOUNTING TIRES ON WHEELS TRIAL FIT EACH WHEEL AND CHECK THAT;
The wheel mounting face freely makes flat contact with the hub, drum brake or mounting face of the vehicle. Spring clip retainers must be removed prior to installation. The wheels are clear of all obstacles when rotated. Wheels are not returnable after mounting tires

DO NOT USE SPACERS TO RESOLVE FITMENT PROBLEMS AS SERIOUS ACCIDENTS AND/OR INJURIES MAY OCCUR.

Only use tires consistent with the vehicle manufacturers recommended rolling diameter, width and load rating. Ensure tires used are a permitted size on the new wheels.

Caution should be taken when determining the proper type of lug nuts to use and must be checked prior to use even when the wheels have been supplied with lug nuts. Check that the lug nut taper is the same as the seat on the wheel (see Fig 1.), that the thread size is correct, and that the lugs are long enough for use. Lug nuts must screw onto studs at least one times the diameter of the stud.



Fig 1. Lug nut taper + seat on wheel.

Tighten lug nuts in a crisscross pattern to the vehicles recommended lug nut torque specification. If not known, refer to the following torque guide.

7/16”	STUD DIA 70-80 ft/lbs	1/2”	STUD DIA 75-85 ft/lbs
12mm	STUD DIA 75-85 ft/lbs	14mm	STUD DIA 85-95 ft/lbs

WARNING
Removing and reinstalling wheels to vehicle can cause serious accidents and/or injuries. Refer to the owners manual of the vehicle to find the correct wheel removal procedure. In the absence of the manual, only persons with prior experience should remove the wheels.

AFTER INSTALLATION
Check proper clearance is evident prior to driving. Drive the vehicle at a slow speed to verify that no clearance issues arise. Lug nuts should be retourqued after approximately 25 miles.

WHEEL CARE
Clean wheels when cool with warm water, mild soap and non-abrasive cloth.
DO NOT use pressure or steam cleaners.
DO NOT use spray on rinse off cleaners.
Once cleaned dry with a non-abrasive towel or chamois.
Repolish polished wheels after cleaning with a quality aluminium wheel polish.
Wheels must be kept clean to avoid damaging the wheels finish.

Showwheels products are intended for normal street use. Please contact us regarding questions on the enclosed information.

LIMITED WARRANTY
Showwheels, INC warrants that our wheels will be free from structural failure under normal and intended use as long as the original retail purchaser owns the product. We further warrant to the original retail purchaser that products manufactured will be free from defects in material and workmanship under normal and intended use for a period of one year from retail purchase.
Chrome alloy wheels have a one year warranty against chrome peeling or lifting on the face of the wheel only. Painted and clear coated wheels have a one year warranty. Polished and billet aluminum wheels oxidize and require regular maintenance, their finish is not covered by this warranty.
OUR SOLE AND EXCLUSIVE OBLIGATION UNDER this warranty shall be to repair or replace at our sole discretion, any product or that does not conform to this warranty and is returned for visual inspection, with a copy of the original sales receipt, to the retail or wholesale dealer from whom the product was originally purchased. Such repair or replacement shall not include removal, installation or freight costs. IN NO EVENT SHALL THE MANUFACTURER BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

THIS WARRANTY IS NOT APPLICABLE IF:
- Damage occurred due to failure to follow the instructions in the Owners Manual.
- Corrosion or damage occurred due to improper maintenance including damage from harsh cleaning chemicals.
- Damage or structural failure occurs as a result of an accident or road conditions.
- Damage or structural failure occurs as a result of motorsport applications.

THIS LIMITED WARRANTY IS THE SOLE EXPRESS WARRANTY GIVEN AND IS IN LIEU OF ALL OTHERS EXPRESS WARRANTIES, WHETHER ORAL OR WRITTEN. ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE HERBY DISCLAIMED.

Some states do not allow limitations on how long an implied warranty last and/or the exclusion or limitation of incidental or consequential damages, so one or more of the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. This warranty expires upon transfer of title of any product by the original retail purchaser. No warranty or representation by anyone other than the manufacturer shall be binding upon. Our wheels, are not designed to be mounted with any accessories or adapters etc., other than those supplied and/or approved in writing by the manufacturer and damage caused by nay such other accessories or adapters is not covered by this warranty.

WHEELS FOR CLASSICS, MUSCLE CARS AND THE LATEST MODELS

UNITED STATES - Showwheels INC, **phone** (714) 524-3100 **fax** (714) 524-8300 **email** sales@showwheelsusa.com
AUSTRALIA - Showwheels PTY LTD, **phone** (03) 8768-8188 **fax** (03) 8768-8190 **email** sales@showwheels.com.au

© Showwheels 2013